

A40B-ADAPT/LC | LC 插头到 LC 插头适配器



产品概述: A40B-ADAPT/LC | LC 插头到 LC 插头适配器

This adapter permits connecting current sources with LC female current connectors to A40B LC female shunt input connectors (the 50 A and 100 A shunts). This can also be used with the A40B ADAPT/LCN if a female mating connector is required.

型号



A40B-ADAPT/LC

LC 插头到 LC 插头适配器



Fluke. 让您的工作畅通无阻。

福禄克测试仪器（上海）有限公司 电话：400-810-3435 ©2025 福禄克公司
04/2025
北京福禄克世禄仪器维修和服务有限公司 电
话：400-615-1563 未经许可，本文档禁止修改
福禄克测试仪器（上海）有限公司上海维修中心 电
话：021-54402301, 021-54401908分机269
福禄克测试仪器（上海）有限公司深圳第一特约维修点
电话：0755-86337229